

AUTOMATED CONTROLLER MANUAL FOR eH End-Hall Ion Source with Hollow Cathode

**Models: eHC 3005A
eHC 30010A
eHC 15015A**



*Kaufman & Robinson, Inc.
1330 Blue Spruce Drive
Fort Collins, CO 80524
Tel: 970-495-0187, Fax: 970-484-9350
Internet: www.ionsources.com*

*Copyright © 2013 by Kaufman & Robinson, Inc.
All rights reserved. No part of this publication
may be reproduced without written permission.
May 2022, Version -
Manual Number: 9007-0034*



This Page Is Intentionally Blank

CONTENTS

i

Contents

1 SAFETY.....	1-1
2 GENERAL DESCRIPTION AND SPECIFICATIONS.....	2-1
2.1 Auto Controller.....	2-2
2.2 Keeper Power Supply.....	2-2
2.3 Emission Power Supply	2-2
2.4 Discharge Power Supply.....	2-3
2.5 Mass Flow Controller(s).....	2-3
3 INSTALLATION	3-1
3.1 Unpack	3-1
3.2 Install in Rack Mount Cabinet.....	3-2
3.3 Ground Connections	3-2
3.4 Connections Between Controller Components	3-3
3.5 Connect Controller to Ion Source.....	3-6
4 INITIAL OPERATION.....	4-1
4.1 Gas.....	4-1
4.2 Power On	4-1
4.3 Operating Mode.....	4-1
4.3.1 Auto Gas Mode	4-1
4.3.1.1 Program Select	4-1
4.3.1.2 Gas Setpoints.....	4-2
4.3.1.3 Keeper Current Setpoint	4-3
4.3.1.4 Emission Setpoints.....	4-3
4.3.1.5 Discharge Parameters	4-4
4.3.1.6 Enable	4-4
4.3.1.7 Standby	4-5
4.3.1.8 Setpoint Adjustment	4-5
4.3.1.9 Saving a Program	4-5
4.3.2 Gas Only Mode	4-6
4.3.2.1 Constant Current Mode.....	4-7
4.3.2.2 Constant Voltage Mode.....	4-9
4.3.3 Manual Gas Mode.....	4-10
5 GENERAL OPERATION.....	5-1
5.1 Description of Ion-Source/Controller Components.....	5-1
6 REMOTE/AUTOMATED CONTROL	6-1
6.1 Remote Control using the DB-25 Connector.....	6-1
6.2 Remote Control using the DB-37 Connector.....	6-1

6.2.1 Remote Enable of the Four Stored Programs using the DB-37 Connector.....	6-1
6.2.2 Remote Gas Channel Setpoint Description for the DB-37 Connector.....	6-2
6.2.3 Remote Analog Setpoint Option on the DB-37 Connector	6-3
6.2.4 Analog Outputs for the DB-37 Connector.....	6-3
6.2.5 Run Fault and Beam Good on the DB-37 Connector.....	6-4
6.2.6 Description of the DB-37 pins	6-4
6.3 Interlock.....	6-7
6.4 Remote Control using the RS-232 Serial Interface	6-8
6.4.1 Interface cable.....	6-8
6.4.2 Communication settings.....	6-8
6.4.3 Communication overview	6-8
6.4.4 Commands, queries and responses	6-8
6.4.4.1 VRB - Verbose Command.....	6-9
6.4.4.2 COM - Enable RS-232 Command or Status Query	6-10
6.4.4.3 *IDN? - Unit Identification Query	6-11
6.4.4.4 *RST – Reset Command.....	6-11
6.4.4.5 *TST? – Self Test Query	6-11
6.4.4.6 OUT - System Level Output Control Command or Status Query	6-12
6.4.4.7 MDE - Mode Set Command or Mode Query	6-13
6.4.4.8 BEAM - Beam Good Query.....	6-13
6.4.4.9 P - Program Value Read/Write Command	6-14
6.4.4.10 R - Monitor Command for Reading the Actual Feedback Values	6-18
6.4.4.11 CFG? – Query current system configuration.....	6-19
6.4.4.12 LRN – Learn Command or Learn Query	6-19
7 DIAGNOSTICS.....	7-1
7.1 Auto Controller.....	7-1
7.2 Keeper Power Supply.....	7-4
7.3 Emission and Discharge Power Supplies.....	7-5
8 APPENDIX.....	8-1
8.1 Auto Controller Setup	8-1
9 WARRANTY	9-1

CONTENTS

iii

Figures

Figure 2-1. Front view of controller for End Hall ion source.	2-5
Figure 2-2. Rear view of controller for End Hall ion source.	2-6
Figure 3-1. Front view of controller for End-Hall ion source.	3-7
Figure 3-2. Rear view of controller for End-Hall ion source.	3-8
Figure 5-1. Schematic block diagram of ion source and power supplies.	5-2

Tables

Table 2-1. Controller Specifications	2-1
Table 2-2. Pin descriptions for the DB-15 MFC connectors on the Auto Controller.	2-4
Table 3-1. Controller Inventory List.....	3-1
Table 3-2. Input power requirements.....	3-2
Table 3-3. Pin descriptions for the rear panel DB-15 female MFC output connectors.	3-5
Table 6-1. Remote program selection using pins 16 and 34 on the DB-37.	6-2
Table 6-2. Pin descriptions for the female DB-37 connector on the Auto Controller.	6-5
Table 6-3. Interlock connections for the Auto Controller.	6-7
Table 7-1. Help codes and error messages for the Auto Controller.....	7-1
Table 7-2. Help codes and error messages for the Keeper Power Supply.	7-4
Table 7-3. Help codes and error messages for the Emission and Discharge Power Supplies.....	7-6



Warning

Danger of High Voltage Personal Injury



Warning

Danger of Personal Injury



Caution

Danger to Equipment

1 SAFETY



Caution: High Voltage. Only technically qualified personnel should install, maintain, and troubleshoot the equipment described herein.

The Auto Controller and power supplies for the End Hall ion source must be installed in a grounded 19-inch (483 mm) rack mount cabinet before operation.

This Page Is Intentionally Blank

GENERAL DESCRIPTION AND SPECIFICATIONS

2-1

2 GENERAL DESCRIPTION AND SPECIFICATIONS

The auto controller package combines modular power supplies and automatic control for operating an End-Hall ion source. The auto controller is designed for use in a standard 19-inch (48cm) rack mount cabinet. The Auto Controller, Keeper Power Supply, Emission Power Supply, Discharge Power Supply and Mass Flow Controller(s) are included in the standard package along with the associated inter-connection and power cables.

The operating specifications, weight and dimensions of each controller are outlined in the following table. This section gives a general overview of the Auto Controller package with more detailed information in the later sections of this manual.

Table 2-1. Controller Specifications

	Nominal Input voltage	Maximum Input Current	Maximum Output	Weight	Height x Depth
Auto Controller	115 V, 1Φ, 50-60 Hz 208-230 V, 1Φ, 50-60 Hz	0.75 A 0.38 A	+/- 15 V, 500 mA DC	3.0 kg (8 lbs)	4.4 x 53 cm (1.75 x 21 in.)
Keeper Power Supply	115 V, 1Φ, 50-60 Hz 208-230 V, 1Φ, 50-60 Hz	14 A 7.5 A	800 V, 2 A DC	7.27 kg (16 lbs)	4.5 x 53 cm (1.75 x 21in.)
Emission Power Supply	115 V, 1Φ, 50-60 Hz 208-230 V, 1Φ, 50-60 Hz	14 A 7.5 A	**	7.27 kg (16 lbs)	4.5 x 53 cm (1.75 x 21in.)
Discharge Power Supply	115 V, 1Φ, 50-60 Hz 208-230 V, 1Φ, 50-60 Hz	14 A*	**	7.27 kg (16 lbs)	4.5 x 53 cm (1.75 x 21in.)

* The discharge power supply output will be limited to 1500 watts when operation with a nominal 115 volt ac input.

** The maximum output depends on the specific power supply ordered.

2-2 GENERAL DESCRIPTION AND SPECIFICATIONS

2.1 Auto Controller

The Auto Controller is designed to be installed in a standard 19 inch rack mount cabinet and is shown in Figures 2-1 and 2-2 along with the Keeper, Emission and Discharge power supplies. The controller communicates with the power supplies through a RS-485 interface. A front panel switch allows selection of either local or remote mode operation. The End Hall ion source can be controlled from the front panels when local mode is selected. When remote mode is selected, the End Hall ion source can be completely controlled via connections to the rear panel. Alternately, programs selected from the front panel can be enabled or disabled from the rear panel when remote mode is selected. Sockets are installed on the rear panel for remote operation using either RS-232 or an Analog interface.

The Auto Controller also interfaces with up to four mass flow controllers using cables that connect to the rear panel. Four relay contacts are also available on the rear panel if additional positive shut off valves are desired for the gas feed system. Three of the gas channels are available for use with the ion source, while gas channel 4 is dedicated to the hollow cathode,

The Auto Controller is connected to the Keeper, Emission, and Discharge power supplies through an RS 485 interface. When the RS-485 interface is not connected the Auto Controller functions as a stand-alone power supply and readout for four mass flow controllers.

2.2 Keeper Power Supply

The Keeper Power Supply is designed to be installed in a standard 19 inch rack mount cabinet and is shown in Figures 2-1 and 2-2 along with the Auto Controller, and the Emission and Discharge power supplies. The Keeper Power Supply provides voltage and current to the Hollow Cathode Electron Source (HCES) for igniting the hollow cathode and keeping the cathode hot enough for thermionic emission of electrons. This power supply communicates to the Auto Controller through a RS-485 interface.

Additional information can be found in the individual manual for the Keeper Power Supply.

2.3 Emission Power Supply

The Emission Power Supply is designed to be installed in a standard 19 inch rack mount cabinet and is shown in Figures 2-1 and 2-2 along with the Auto Controller, and the Keeper and Discharge power supplies. The Emission Power

GENERAL DESCRIPTION AND SPECIFICATIONS

2-3

Supply provides a negative voltage to the hollow cathode after it is ignited by the Keeper Power Supply and controls the electron current emitted from the HCES. This power supply communicates to the Auto Controller through a RS-485 interface.

Additional information can be found in the individual manual for the Keeper Power Supply.

2.4 Discharge Power Supply

The Discharge Power Supply is designed to be installed in a standard 19 inch rack mount cabinet and is shown in Figures 2-1 and 2-2 along with the Auto Controller and the Keeper and Emission power supplies. The Discharge Power Supply provides voltage and current to the anode of the End-Hall ion source. This power supply communicates to the Auto Controller through a RS-485 interface.

Additional information can be found in the individual manual for the Discharge Power Supply.

2.5 Mass Flow Controller(s)

The mass flow controller (MFC) or controllers are supplied when ordered as a complete system. The controllers are connected to the gas feed for the ion sources as close as possible to the gas feedthrough on the vacuum system. Up to four mass flow controllers can be attached to the Auto Controller. The gas flows can be set as a constant ratio or they can be set independently.

The Auto Controller can be used with a variety of mass flow controllers. However, the cables may vary depending on the mass flow controller provided in the order. The pin descriptions for the female DB-15 connectors on the back of the Auto Controller are given below in Table 2-2.

GENERAL DESCRIPTION AND SPECIFICATIONS

2-5



Figure 2-1. Front view of controller for End Hall ion source.




Figure 2-2. Rear view of controller for End Hall ion source.

3 INSTALLATION

This section describes how to install the Kaufman & Robinson, Inc., KRI® Controller package for the hollow cathode version of the End Hall Ion Source.

3.1 Unpack

Unpack the Controller package for the End Hall Ion Source. Prior to shipment, the Controller was tested with the ion source to insure quality and verify the standard range of operation. As soon as the Controller has been completely removed from all packing materials, a visual inspection should be made to determine if there has been any damage to the components during shipment. Use the packing lists provided to confirm the completeness of order. If any damage has occurred, contact Kaufman & Robinson, Inc., in addition to the shipping company, to report the damage - see Section 8. Retain packaging materials for any future shipments.

Table 3-1 is an inventory list for the controller package. The inventory list is for the standard package so some items may or may not be included depending on the particular order. Refer to the packing slip for the part numbers. For any questions or discrepancies concerning either the inventory or shipping list, see Section 8 to contact Kaufman and Robinson, Inc. Refer to Section 2 – General Description and Specifications for additional information about the controller.

Table 3-1. Controller Inventory List

Quantity	Description
1	Auto controller
1	Keeper Power Supply
1	Emission Power Supply
1	Discharge Power Supply
4	Input Power cables
1	Red wire
1	Black wire
1	Green/Yellow daisy chain ground wire
2	Mass flow controllers
2	Mass flow controller cables 6m (20 ft) cable
1	Operating cable, 6m (20 ft) cable
3	Interface cables, RS-485

3.2 Install in Rack Mount Cabinet

The Controller is designed to be mounted in a standard 19-inch (48 cm) rack mount cabinet. To assure that the power cable that came with each controller is connected to that controller, the power cables can be connected as each controller is installed in the cabinet. Do not connect to input power before the installation is complete. The input power requirements are given below in Table 3-2. Universal single phase 50-60 Hz input power of 85 to 275 volts can be used, so no modification is required to use either a nominal 115 or 208-230 volt input.

Table 3-2. Input power requirements

Module	Nominal Input Voltage	Maximum Input Current
Auto Controller	115 V, 1 Φ , 50-60 Hz	0.75 A
	208-230 V, 1 Φ , 50-60 Hz	0.35 A
Keeper Power Supply	115 V, 1 Φ , 50-60 Hz	14 A
	208-230 V, 1 Φ 50-60 Hz	7.5 A
Emission Power Supply	115 V, 1 Φ , 50-60 Hz	14 A
	208-230 V, 1 Φ 50-60 Hz	7.5 A
Discharge Power Supply	115 V, 1 Φ , 50-60 Hz*	14 A*
	208-230 V, 1 Φ , 50-60 Hz	14 A

* The discharge power supply output will be limited to 1500 watts when operating with a nominal 115 volt ac input.

The Auto Controller, Keeper Power Supply, Emission Power Supply, and Discharge Power Supply should be mounted one above the other in the cabinet. See Fig. 3-1 for the relative locations of the individual rack mounted units. The wiring and cables may not reach all the controller connections if installed in a different order.

3.3 Ground Connections

An earth ground connection is required for both safety and correct operation. Earth ground should be connected to the vacuum chamber in which the ion source is to be operated as well as the cabinet in which the Controller is installed. Make sure that qualified technical personnel make these ground connections. These ground connections are independent of the ground connections described below in Section 3.4.

3.4 Connections Between Controller Components

The connections between Controller components are shown in Fig. 3-2, which shows the rear panels of the Auto Controller, Keeper, Emission, and Discharge power supplies. The individual connections required are given below:

- If the 6 meter (20 ft.) input power supply cables were not connected to the individual power supplies when they were installed in the cabinet, connect them now. Use plugs that will match the input power sources. Again, do not connect to Input Power before the installation is complete.
- Attach the 4 pin (female) plug connector of the 6 meter (20 feet) operating cable to the connector on the electrical feedthrough. The connections for the other end of this cable are described below.
- Insert the end of the operating cable BLUE wire into one of the (+) positive connectors located on the rear panel of the Discharge Power Supply and tighten the screw above the appropriate connector.
- Insert the end of the operating cable BLACK wire into one of the (-) negative connectors located on the rear panel of the Discharge Power Supply and tighten the screw above the appropriate connector.
- Insert the end of the operating cable RED wire into one of the (-) negative connectors located on the rear panel of the Keeper Power Supply and tighten the screw above the appropriate connector.
- Insert the end of the operating cable ORANGE wire into one of the (+) Positive connectors located on the rear panel of the Keeper Power Supply and tighten the screw above the appropriate connector.
- Insert one end of the short RED wire into one of the (-) negative connectors located on the rear panel of the Keeper Power Supply and tighten the screw above the appropriate connector.
- Insert the other end of the short RED wire into one of the (-) negative connectors located on the rear panel of the Emission Power Supply and tighten the screw above the appropriate connector.
- Insert one end of the short BLACK wire into one of the (+) positive connectors located on the rear panel of the Emission Power Supply and tighten the screw above the appropriate connector.

- Insert the other end of the short BLACK wire into one of the (-) negative connectors located on the rear panel of the Discharge Power Supply and tighten the screw above the appropriate connector.
- Attach the ring terminal end of the operating cable GREEN/YELLOW wire into the ground stud of the Discharge Power Supply.
- Attach the ground connections using the GREEN/YELLOW wire with the four ring terminals as follows; Connect the four ring terminals to the four ground studs on the Auto Controller rear panel, the Keeper Power Supply rear panel, the Emission Power Supply rear panel, and the Discharge Power Supply rear panel. Tighten the nuts on the ground studs. Connect the remaining green striped yellow wire to the chassis system ground for the electrical cabinet that the power supplies are installed in.
- Attach the three RS-485 cables to the connector labeled “RS-485 X 4” located on the back panel of the Auto Controller as shown in Figure 3-2. The RS-485 connectors are not device specific, so they can be plugged into any of the RS-485 connectors.
- Attach the other ends of the three RS-485 cables to the connectors labeled “RS-485” located on the power supply back panels, one for the Keeper, one for the Emission, and one for Discharge as shown in Figure 3-2.
- Attach the ion source MFC cable to the connector labeled “MFC 1” located on the back panel of the Auto Controller. Attach the other end to the MFC for the ion source. The pin descriptions for the DB-15 Female connectors are shown below in Table 3-3.
- Attach any additional ion source MFC cables to the connectors labeled “MFC 2”, “MFC 3” located on the back panel of the Auto Controller. Attach the other ends of these cables to the corresponding MFC’s for the ion source.
- Attach the hollow cathode MFC cable to the connector labeled “MFC 4” located on the back panel of the Auto Controller. Attach the other end to the MFC for the hollow cathode. The pin descriptions for the DB-15 Female connectors are shown below in Table 3-3.
- The mass flow controller is defined by the ion-source application. The mass flow controller should be mounted as close as possible to the vacuum chamber. See the MFC manual. If an additional positive shut off valve is to be used with the MFC’s, they should be located directly downstream of the MFC (between the MFC and the vacuum chamber wall. Additionally, if a

INSTALLATION

3-5

purifier is used in the hollow cathode gas line, it should be located upstream from the mass flow controller.

- There is a two pin interlock connector located on the back of the Auto Controller. The unit comes supplied with a jumper installed in the interlock connector. The Auto Controller disables the outputs of the power supplies if this contact is open. If a system interlock is used, a separate isolated contact should be connected to each of the four interlock connectors.
- If remote control of the auto controller is used, that cable can be attached at this time to the female DB-25 connector, the female DB-37 connector, or the female DB-9 connector. These remote interfaces require knowledge of the ion source operation, which is given in the next two sections of this manual. The detailed descriptions for remote control are in Section 6 REMOTE/AUTOMATED CONTROL of this manual.
- The connections between the pressure regulators and the flow controller valves should be made with clean (passivated or hydrocarbon free) stainless steel tubing, with all fittings properly installed. Plastic tubing should not be used to avoid contamination of the gas.

Table 3-3. Pin descriptions for the rear panel DB-15 female MFC output connectors.

Pin Number	Description
1	Common for 0-5 volt setpoint.
2	0-5 V flow read back signal from MFC, referenced to pin 10.
3	Not used.
4	Valve off. Connected to common when the setpoint flow is set to zero or when the Auto Controller is in Standby, otherwise floated.
5	+15 V, referenced to pin 9.
6	-15 V, referenced to pin 9.
7	Not used.
8	0-5 V setpoint out to MFC, referenced to pin 1.
9	Power common for ± 15 V.
10	Common for read back signal.
11	Not used.
12	Not used.

Pin Number	Description
13	Not used.
14	Chassis Ground.
15	Not used.

3.5 Connect Controller to Ion Source

If the Ion Source has not been installed in the vacuum chamber, do so now, using the Installation/Inspection description in the ion source manual. The ion source installation procedures cover installation of the ion source, vacuum cables, gas tubing inside the vacuum chamber, as well as electrical and gas feedthroughs in the wall of the vacuum chamber. Once installed, connect the operating cable to the electrical feedthrough.

- As the final installation step, turn off the front panel power switches on the Auto Controller, Keeper Power Supply, Emission Power Supply, and Discharge Power Supply. Then plug the power cables of the individual controllers into appropriate input power sources. See Table 3-1 above for input power requirements.

The installation for the automated power controller is now complete.

INSTALLATION

3-7



Figure 3-1. Front view of controller for End-Hall ion source.




Figure 3-2. Rear view of controller for End-Hall ion source.

4 INITIAL OPERATION

This initial operation is done locally from the front panel and serves to both demonstrate and provide familiarization with operation. Make sure that the Auto controller is switched to local mode. The description in this section assumes that the installation sequence described in Section 3 of this manual and in the ion source manual has been carried out.

4.1 Gas

High-purity (99.999+%) argon, oxygen, or nitrogen gas can be used in the ion source. The hollow cathode requires 99.999% pure argon gas for operation. Refer to the Hollow Cathode Electron Source manual or the hollow cathode section of the ion source manual for special considerations required for the hollow cathode gas supply. For other process gases, please contact Kaufman & Robinson, Inc. The bottle, regulator, and mass flow controller(s) should be installed and gas lines evacuated as described in the Ion Source manual.

4.2 Power On

Switch on the front panel power switches to the Auto Controller, Keeper, Emission, and Discharge power supplies. These switches are the rocker type switches located on the far left of the four panels.

4.3 Operating Mode

There are three selectable operating modes for the Auto Controller. These three modes include Auto Gas, Manual Gas, and Gas Only. All three modes can be selected using the white Operating Mode button on the front panel of the auto controller. Auto Gas and Manual Gas modes are available only when the Auto Controller has established communication with the power supplies.

4.3.1 Auto Gas Mode

When using Auto Gas mode, the gas is automatically adjusted to maintain constant discharge current and voltage once the ion source is running. Check to see if the green Auto Gas LED indicator above the Operating Mode button is on. If it is not, then continue to press and release the Operating Mode button until the green Auto Gas LED is on.

4.3.1.1 Program Select

The Auto controller is shipped with four programs stored. Pressing and releasing the white Program Select button will increment to the next

program as indicated by the numbered red LED's on the left side of the Program Select button. The program values will be displayed on the front panels for each program. Program 1 may already be selected when the unit is powered on, if it is not, then press and release the program select button until the red LED for program 1 is on for the initial operation.

The other programs can still be viewed after the Auto Controller is enabled with one of the programs running. When a program is running and "Program Select" is pressed, the setpoint values of the next program will be displayed for two seconds before switching to that program. This gives time to review the programs before deciding which one to run. Pressing again within two seconds moves to the next program, etc. Cycling around to the program that's currently running will continue operation without change. Otherwise, the parameters will be ramped to the newly selected program.

4.3.1.2 Gas Setpoints

There are four gas channels. Pressing and releasing the Gas Channel Select button will increment to viewing the gas setpoint in sccm, for the next gas channel for each program. In the Auto Gas mode, the gas is automatically adjusted to maintain constant discharge current and voltage once the ion source is running. The setpoints act as the starting point from which the gas is adjusted. When more than one gas is blended together, a constant ratio of the gas is adjusted based on the initial gas setpoints to maintain the discharge voltage and current for gas channels 1, 2 and 3.

Gas channel 4 is reserved for the Hollow cathode. The setpoint on this MFC is the operating flow for the hollow cathode. Additionally, the gas for the hollow cathode is always flowing at this setpoint value or a preprogrammed minimum flow regardless of the enable/standby selection on the front panel. This is to insure that the minimum gas flow requirement of 15 minutes before starting and after running is met. The Auto Controller can be switched off if it is necessary to turn off the gas flow for other process requirements when operating from the front panel. Note that the Keeper, Emission, and Discharge will all display HLP 7 when the Auto Controller is turned off. This is to indicate that they have lost communication with the Auto controller. These HLP 7 messages will be cleared when the Auto controller is turned back on. A shut off signal for the hollow cathode gas is also available for remote shut off without turning off the Auto Controller.

During startup of the hollow cathode, the automatic sequencing of the

Auto Controller will raise the gas flow to 100 sccm to ignite the hollow cathode in the Auto gas or Manual gas operating modes. After ignition in these two modes, the gas controller will then drop the flow to the operating flow. The recommended operating flow is 10 sccm for up to 10 amps of cathode emission current. One sccm should be added to this flow for each additional ampere of emission current above 10 amps. Operation is possible using less than the recommended minimum, but will reduce the lifetime of the hollow cathode insert. Contact KRI for advice on using less flow for the hollow cathode if necessary.

The gas flow may be adjusted by selecting the gas channel and turning the knob on the front panel of the gas controller before the auto controller is enabled. For the initial operation, leave the gases set at the programmed setpoint(s).

4.3.1.3 Keeper Current Setpoint

The setpoint for the keeper current in amps is shown in the display labeled Keeper Amps on the Keeper Power Supply. Notice that the yellow setpoint LED below the display is on to indicate that the setpoint is being viewed. Once the Auto Controller is enabled, the run value will be displayed and the green run LED will be on.

The keeper current setpoint can be adjusted by turning the Setpoint Adjust knob on the front of the Keeper Power Supply. Note: If the emission current is set to less than 0.5 amps, then it may be desirable to increase the keeper current to 2.0 amps to promote longer cathode lifetimes. For the initial operation, leave the keeper current at the 1.5 amp setpoint.

4.3.1.4 Emission Setpoints

The setpoints for the emission voltage in volts and the emission current in amps are displayed on the front panel of the Emission Power Supply in the displays labeled Volts and Amps. Notice that the yellow setpoint LED below the display is on to indicate that the setpoint is being viewed. Once the Auto Controller is enabled, the run values will be displayed and the green run LED will be on.

The Emission voltage and current setpoints can be adjusted by turning the Setpoint Adjust knob on the front of the Emission Power Supply. The setpoint being adjusted by the knob is indicated by the green LED's on the front panel labeled Amps and Volts. These LED's are located above and below the white Select button on the front panel of the Emission Power

Supply. Pressing and releasing the Select button will switch the parameter being adjusted from Amps (emission current) to Volts (emission voltage) or from Volts to Amps. This can only be adjusted independently, but is also adjusted automatically when adjusting the Discharge current. This maintains the same Emission to Discharge current ratio. For the initial operation, leave the Emission at the program setpoint.

4.3.1.5 Discharge Parameters

The setpoints for the discharge voltage in volts and the discharge current in amps are displayed on the front panel of the Discharge Power Supply in the displays labeled Discharge Volts and Discharge Amps. Notice that the yellow setpoint LED below the display is on to indicate that the setpoint is being viewed. Once the Auto Controller is enabled, the run values will be displayed and the green run LED will be on.

The discharge voltage and current setpoints can be adjusted using the Setpoint Adjust knob on the front of the discharge controller. These adjustments can be made when the Auto Controller is in Standby or when it is Enabled. The setpoint being adjusted by the knob is indicated by the green LED's on the front panel labeled Amps and Volts. These LED's are located above and below the white Select button on the front panel of the Discharge Power Supply. Pressing and releasing the Select button will switch the parameter being adjusted from Amps (discharge current) to Volts (discharge voltage) or from Volts to Amps. For the initial operation, leave the discharge voltage and current at the program setpoints.

4.3.1.6 Enable

Press and release the white Enable/Standby button on the front panel of the Auto Controller. Notice that the yellow Standby LED under the button turns off and the green Enable LED above the button turns on. The same LED transition from Standby to enable also happens on the Keeper, Emission, and Discharge Power Supplies as the Auto Controller sequences them on. The gas flow will automatically be adjusted until the program 1 parameters are reached.

Note that the operating range of the ion source may be limited by the vacuum facility pump speed or other process that take place while the ion source is running.

4.3.1.7 Standby

Press and release the white Enable/Standby button on the front panel of the Auto Controller. Notice that the yellow Standby LED under the button turns on and the green Enable LED above the button turns off. The same LED transition from Enable to Standby also happens on the three power supplies as the Auto Controller sequences them off.

The auto controller updates the program and saves a new starting gas flow so the discharge parameters will be reached more quickly the next time the program is run.

4.3.1.8 Setpoint Adjustment

When the Auto Controller is in the Auto Gas mode, the ion source parameters can be adjusted before the auto controller is enabled as described above. When the values are adjusted, the program LED will flash to indicate that the program has not been saved. The new values can be acquired by pressing and holding the acquire setpoints button until the program LED stops flashing.

Once the controller is enabled, the discharge voltage and current can be adjusted. Adjusting the discharge current when the auto controller is enabled also adjusts the Emission current. In this case, the Emission current becomes a fixed ratio of the Emission current to discharge current based on the Emission and discharge current setpoints before the Auto Controller was enabled. For example: The discharge current and Emission current are set to 4.0 amps and 4.4 amps before enabling the auto controller; after enabling, the discharge current is adjusted to 5.0 amps and the Emission current will automatically be adjusted to 5.5 amps. Press and hold the acquire setpoints button until the program indicator stops flashing to acquire the new setpoints; the old program values will be overwritten with the new values. Pressing the program button once before new values are acquired will clear any adjustments and revert back to the original program.

4.3.1.9 Saving a Program

The first step is to select the operating condition. Review the ion source manual to select an operating condition that is within the range of the particular ion source.

Note that the vacuum facility pump speed or other processes that take

place while the ion source is running may limit the operating range of the ion source. A program can be saved when the Auto Controller is enabled or when it is in standby.

When the Auto Controller is in standby, use the program select button to select the program number that will be overwritten. Adjust the setpoints to the desired values as described above and then press and hold the white Acquire Setpoints button on the Auto Controller until the red program LED stops flashing. When this LED stops flashing, the program has been saved.

When the Auto Controller is enabled, first select the program number where the new setpoints will be saved. Next, adjust the setpoints to the desired values and acquire setpoints as described above in Section 4.3.1.8 Setpoint Adjustment

Repeatedly pressing and releasing the Select Program button will cycle through the programs. If more than two seconds elapses before the Select Program button is pressed and released, the Auto Controller will commit to the program being viewed when it is in the enable state.

4.3.2 Gas Only Mode

When gas only mode is selected, the Auto Controller functions as a gas controller only. Independent control of each of the four gas channels is possible. The description below outlines the use with one gas channel for the ion source even though similar operation could be obtained using all three gas channels that are available for the ion source. Gas channel 4 is dedicated to the Hollow Cathode. Use the Operating Mode Select button to select the Gas Only mode with the Auto Controller in standby. Selecting the Gas Only mode releases control of the power supplies so that they can be operated independently. There is no feedback to maintain the discharge parameters. However, at any time during the operation in gas only mode, the setpoints can be acquired for operation later using the Auto Gas mode or the Manual Gas mode.

Note: In Gas Only Mode, the program LED does not flash unless a gas setpoint has changed

Note that if there is no communication link to any of the power supplies, the Auto Controller will only function in the gas only mode, which must be selected to clear the HLP 7 message from the display. There will be no communication link if the power is switched off to any of the power supplies or if any RS-485 cable connection on the rear panel is not connected to Auto

Controller or any of the power supplies.

There are two modes of operation for the discharge: Constant Current Mode or Constant Voltage Mode. The Constant Current Mode allows for small variations in the discharge voltage while maintaining a constant current and is recommended when operating at 120 V and below. The Constant Voltage Mode will allow for small variations in discharge current and maintains a constant voltage. Constant Voltage Mode is recommended for operation above 120 V.

4.3.2.1 Constant Current Mode

The operating condition selected for this demonstration is with a 2.5A, 120 V, discharge, which is Constant Current Mode operation. These conditions are based on a vacuum pump speed of 800 liters per second. Operating parameters for other pump speeds and gases can be found in the Ion Source Manual.

Note that the operating range of the ion source may be limited by the vacuum facility pump speed or other process that take place while the ion source is running.

- Press the white Enable/Standby button on the Auto Controller.
- Select Gas 4 using the white Gas Channel Select button on the Auto Controller and then turn the Gas Adjust knob to 10 sccm. Gas should be allowed to flow through the hollow cathode for 15 minutes at 10 sccm before proceeding to the next step
- Select Gas 1 using the white Gas Channel Select button on the Auto Controller and then turn the Gas Adjust knob to 10 sccm.
- Select Gas 4 using the white Gas Channel Select button on the Auto Controller and then turn the Gas Adjust knob to 100 sccm.
- Turn the knob on the Keeper Power Supply until 1.5 amps is indicated in the Keeper Amps display.
- Turn the knob on the Emission Power Supply until 2.7 amps is indicated in the Emission Amps display. Note that the Emission current in amps is usually set equal to or up to 10% greater than the discharge current.

- Use the white Select button on the Discharge Power Supply to select Volts. Turn the knob on the Discharge Power Supply until the discharge voltage is set to maximum as indicated on the Discharge Volts display.
- Use the white Select button on the Discharge Power Supply to select Amps. Turn the knob on the Discharge Power Supply until the discharge current is set to 2.5 amps as indicated on the Discharge Amps display.
- Press the white Enable/Standby button on the Keeper Power Supply. And wait a couple of seconds for the keeper to start the hollow cathode as indicated by the Keeper Amps display reading 1.5 amps.
- Reduce the flow to gas channel 4 to 10 sccm.
- Press the white Enable/Standby button on the Emission Power Supply.
- Press the white Enable/Standby button on the Discharge Power Supply.
- Adjust the gas flow for channel 1 using the Gas Adjust Knob on the Auto Controller until the discharge voltage is approximately 120 V.
- Operate the ion source for at least 10 minutes to clean any contaminants from the ion source that may have been introduced while at atmosphere.
- The discharge voltage will vary slightly during this time. Adjust the gas flow after the 10 minutes to obtain a discharge voltage of approximately 120 V.
- At this point the operating conditions can be saved as a program to be used later in the Auto Gas mode or the Manual Gas mode. To do this press and hold the white Acquire Setpoints button for two seconds. This saves the new parameters to the active program.
- Stop operation by putting the discharge, emission, and keeper power supplies into Standby in that order by pressing the white Enable/Standby button on each.
- Put the gas flow into Standby by pressing the white Enable/Standby button on the auto controller.

4.3.2.2 Constant Voltage Mode

The operating condition selected for this demonstration is with a 2.5 A, 150 V discharge, which is Constant Voltage Mode operation. The following conditions are based on a vacuum pump speed of 1600 liters per second. Operating parameters for other pump speeds and gases can be found in the Ion Source Manual.

Note that the vacuum facility pump speed or other processes that take place while the ion source is running may limit the operating range of the ion source.

- Press the white Enable/Standby button on the Auto Controller.
- Select Gas 4 using the white Gas Channel Select button on the Auto Controller and then turn the Gas Adjust knob to 10 sccm. Gas should be allowed to flow through the hollow cathode for 15 minutes at 10 sccm before proceeding to the next step
- Select Gas 1 using the white Gas Channel Select button on the Auto Controller and then turn the Gas Adjust knob to 10 sccm.
- Select Gas 4 using the white Gas Channel Select button on the Auto Controller and then turn the Gas Adjust knob to 100 sccm.
- Turn the knob on the Keeper Power Supply until 1.5 amps is indicated in the Keeper Amps display.
- Turn the knob on the Emission Power Supply until 2.7 amps is indicated in the emission Amps display. Note that the emission current in amps is usually set equal to or up to 10% greater than the discharge current.
- Use the white Select button on the Discharge Power Supply to select Amps. Turn the knob on the Discharge Power Supply until the discharge current is set to maximum as indicated on the Discharge Amps display.
- Use the white Select button on the Discharge Power Supply to select Volts. Turn the knob on the Discharge Power Supply until the discharge voltage is set to 150 volts as indicated on the Discharge Volts display.

- Press the white Enable/Standby button on the Keeper Power Supply. And wait a couple of seconds for the keeper to start the hollow cathode as indicated by the Keeper Amps display reading 1.5 amps.
- Reduce the flow to gas channel 4 to 10 sccm.
- Press the white Enable/Standby button on the Emission Power Supply.
- Press the white Enable/Standby button on the Discharge Power Supply.
- Adjust the gas flow for channel 1 using the Gas Adjust Knob on the Auto Controller until the discharge current is approximately 2.5 A.
- Operate the ion source for at least 10 minutes to clean any contaminants from the ion source that may have been introduced while at atmosphere.
- The discharge current will vary slightly during this time. Adjust the gas flow after the 10 minutes to obtain a discharge current of approximately 2.5 A.
- At this point the operating conditions can be saved as a program to be used later in the Auto Gas mode or the Manual Gas mode. To do this press and hold the white Acquire Setpoints button for two seconds. This saves the new parameters to the active program.
- Stop operation by putting the discharge, emission and keeper power supplies into Standby in that order by pressing the white Enable/Standby button on each controller.
- Put the gas flow into Standby by pressing the white Enable/Standby button on the auto controller.

4.3.3 Manual Gas Mode

Manual Gas mode operates the same as the auto gas mode except that there is no feedback loop for the gas flows to maintain the anode parameters. This being the case, the gas channels can all be independently adjusted during operation, where this was not possible in the Auto Gas mode.

INITIAL OPERATION

4-11

The discharge parameters can be set up for either constant voltage mode operation or constant current mode operation as described above for the manual gas operating mode.

Constant voltage mode is typically used for discharge voltages of 120 volts or more. The discharge current is usually set to maximum, while the operating voltage is set to the desired value on the front panel. The gas flow to the ion source is then adjusted to control the ion source current.

Constant current mode is typically used for discharge voltages less than 120 volts. The discharge voltage is usually set to maximum, while the operating current is set to the desired value on the front panel. The gas flow to the ion source is then adjusted to control the ion source voltage.

Select the Manual Gas mode using the Operating Mode button. Select the program to run using the Program Select button. Enable the program by pressing the Enable/Standby button on the Auto Controller. Press the Enable/Standby button again to stop the program and put the units into Standby.

Saving a program is accomplished in the same manner as described above for the Auto Gas and Gas Only operating modes.

This Page Is Intentionally Blank

5 GENERAL OPERATION

The quickest way to start operation of the KRI Ion Source and its Controller is to follow the sequence described in Section 4, Initial Operation. This section gives a general overview of the ion source power supplies and their interconnection with the ion source.

5.1 Description of Ion-Source/Controller Components

The operation of the End Hall Ion Source with its power supplies can be generally understood by reference to the schematic block diagram of Fig. 5-1.

The commonly used symbols for the currents and voltages are also shown in Fig. 5-1. The voltage and current of the Keeper Power Supply are V_k and I_k ; the voltage and current of the Emission Power Supply are V_b and I_b ; while the voltage and current of the Discharge Power Supply are V_d and I_d . The discharge voltage and current has sometimes been referred to as the anode voltage and current and given as I_a and V_a , but only the symbols I_d and V_d will be used herein.

A mass flow controller (MFC) establishes a gas flow through the hollow cathode of 100 sccm to establish a high enough pressure that a Paschen discharge can be established when the keeper voltage, V_k , of 800 volts is applied. The Paschen discharge heats the hollow cathode until surfaces inside the cathode tube are hot enough for thermionic emission. Once the thermionic emission is established, only about 10 – 40 volts are required to keep the hollow cathode ignited using 1.5 amps of keeper current, I_k . After ignition, the gas flow to the hollow cathode is reduced to the operating flow, typically 10 sccm.

After the hollow cathode is ignited, a negative bias voltage, V_b , is applied to the cathode to establish the electron emission. The Emission current, I_b , is the amount of electron current in amps that is available to operate the ion source.

With the Emission current initialized, the other MFC supplies gas to the ion source. The neutral gas molecules flow into the anode. The Discharge Power Supply applies a positive potential, V_d , to the anode. Some of the electrons from the hollow cathode are attracted to the positive anode, but they are impeded by a magnetic field (not shown in the figure). This magnetic field confines the electrons until they bump into neutral gas atoms and knock off electrons, creating positive ions in the process. The ions are repelled from the positive anode and flow outward. Some of the electrons from the hollow cathode mix with the outward flowing ions to equalize the charge. This mixture of ions and electrons is the neutralized ion beam, although it is usually referred to as the ion beam or plasma beam.




Figure 5-1. Schematic block diagram of ion source and power supplies.

6 REMOTE/AUTOMATED CONTROL

The Auto controller has a variety of remote control options available. These options include a female DB-25 interface, female DB-37 analog/digital interface, and a female DB-9 RS-232 serial interface. Note: The Auto Controller must be in Standby to switch between local and remote operating modes.

6.1 Remote Control using the DB-25 Connector

The DB25 pin-out has been designed to be “drop in” compatible with the old Mark II power supply to enable a minimum impact upgrade for the end user, for a filament version only. With the hollow cathode version, only the remote enable pins 7 and 20 are active. When using the remote enable, the programs are entered and stored using the front panel as described in Operation Sections 4 and 5 of this manual. After the programs have been acquired using the front panel, switch the front panel from local to remote. Connect pin 7 (Beam on) to pin 20 (Beam on return) on the rear panel DB-25 connector to enable the program selected from the front panel.

6.2 Remote Control using the DB-37 Connector

The DB-37 connector is an extended control set which gives the operator full access to the Auto Controller inputs and outputs. There are two main options when using the DB-37 connector for remote control of the Auto Controller. One option is to enable one of the four programs stored in the auto controller. These programs can be acquired using the front panel as described in the operation Sections 4 and 5 of this manual. The other option is to input the desired operating parameters and then use the Auto Controller for sequencing and/or automatic feedback to keep the discharge parameters constant. **If the DB-37 connector is to be used as a remote interface, then pin 18 (DB-37 Select) must be connected to common pin 7 or 8 on the DB-37 for all the options described below.**

6.2.1 Remote Enable of the Four Stored Programs using the DB-37 Connector

The DB-37 I/O allows program selection through the rear input ports. When using remote enable, the programs can be acquired using the front panel as described in Operation Sections 4 and 5 of this manual.

Pins 16 (Program select 0) and pin 34 (Program select 1) on the rear panel DB-37 connector are used to select the four programs. Making connections

to common pin 8 or leaving the connections open as indicated below in Table 6-1 selects the programs. Once the program is selected, connecting remote enable pin 36 to common pin 7 or 8 on rear panel DB-37 connector enables it. Removing the connection between pin 36 and pin 7 or 8 returns the Auto Controller to Standby. Switching to another program while the Auto Controller is enabled will instantly commit to running the program that has been selected.

Table 6-1. Remote program selection using pins 16 and 34 on the DB-37.

Program Number	Pin 34	Pin 16
1	Open	Open
2	Open	Common
3	Common	Open
4	Common	Common

6.2.2 Remote Gas Channel Setpoint Description for the DB-37 Connector

The gas channel setpoints all use 0-5 volt inputs (referenced to pin 13) that correspond with 0 to the maximum output for the MFC in sccm. A setpoint of zero also de-energizes the gas relay on the rear panel and sends the valve off command to the mass flow controller. The gas relays are also de-energized and the valve off commands are sent to the mass flow controllers when the Auto Controller is in standby. This is true except for gas channel 4, which is dedicated to the hollow cathode. The hollow cathode gas will flow at a preprogrammed minimum flow if a setpoint value less than this minimum is programmed. The preprogrammed minimum is typically between 5 and 10 sccm. If necessary, this minimum can be field programmed to another value; see appendix. This gas flow can be disabled for other process considerations by connecting pin 15 (gas CH₄/HC off) to one of the common pins 7 or 8 on the DB-37 connector. However, the hollow cathode gas should be allowed to flow for 15 minutes before and after operating the hollow cathode. Turning the gas flow off momentarily during this 15 minute time period is acceptable. It is often desirable to turn off the gas momentarily to achieve a minimum pressure in the vacuum chamber before starting a process.

The gas channel setpoints function differently depending on the operating mode selected. The Auto Gas, Manual Gas, and Gas Only modes are selected from the front panel. The functions of the gas setpoints are described below for these three operating modes.

- **Remote Gas Channel Setpoints using Auto Gas or Manual Gas Modes**

The remote gas setpoints are not available when using the auto or manual gas modes, instead the starting gas flows are established by programming them from the front panel for each program. The gas for channel 4 is reserved for the hollow cathode. This gas flows continuously at the front panel set point value regardless of the enable/standby selection. For processes that require a minimum vacuum base pressure, this gas flow can be disabled by connecting pin 15 (gas CH4 off) to common pins 7 or 8. See the Hollow Cathode Electron source manual for the gas flow requirements before and after the hollow cathode is started.

- **Remote Gas Channel Setpoints Using the Gas Only Mode**

When the Gas Only mode is selected from the front panel, the Auto Controller continuously responds to the applied gas setpoints once the Auto Controller is enabled.

6.2.3 Remote Analog Setpoint Option on the DB-37 Connector

The remote analog setpoint option allows active control over the setpoints while the Auto Controller is enabled in the auto gas mode. The four stored programs are not available with the remote analog setpoint option.

Switch the front panel from local to remote and also connect Remote setpoint pin 17 to common pin 7 or 8 on the DB-37. This selects the remote setpoint options for both the DB-25 and the DB-37 ports. The remote analog setpoints are applied to the analog pins described below in Table 6-2. To enable the system, connect the remote enable pin 36 to common pin 7 or 8 on the rear panel DB-37 connector.

The starting gas setpoints are taken from the front panel when operating in Auto Gas mode. The auto controller then automatically adjusts the gas to maintain the program values for the discharge voltage and current, while maintaining the ratio established by the starting gas setpoints.

6.2.4 Analog Outputs for the DB-37 Connector

The analog outputs for monitoring the operating parameters are available on the on the DB-37 connector as described below in Table 6-2. The analog outputs are available in both remote and local operating modes.

The setpoints for each of the four programs can be reviewed in standby

mode by selecting the program as indicated in Table 6-1 above. Note that the setpoints can only be viewed with the Auto Controller in standby. Once a program is enabled, the values for the analog outputs are the actual values.

6.2.5 Run Fault and Beam Good on the DB-37 Connector

The Run Fault and Beam Good are available for additional monitoring of the operational state of the auto controller and associated power supplies. These pins are described below in Table 6-2.

A Run Fault occurs when the discharge fails to start or goes out in Auto Gas mode. It also occurs if the operating parameters are out of range for more than 54 seconds.

In order for these operating parameters to be in range:

1. The gas flow must be within 50% of the setpoint.
2. The Discharge current must be within ± 1.28 amps of the setpoint.
3. The Discharge voltage must be within ± 12.8 volts of the setpoint.
4. The Emission current must be within 75% of the discharge current.

When a run fault occurs, the Auto Controller reverts to Standby and a help code or error message is displayed on the front panel of the Auto Controller. Use the help codes and error messages defined in Diagnostics Section 7 of this manual to determine the cause of the Run Fault. The help code or error message is cleared when the remote enable pin 36 is released from common pin 7 or 8.

The Beam Good function gives a real time check of the operating parameters. If the operating parameters are in range, the two Beam Good pins are shorted together. If the operating parameters are out of range, then the beam good pins are open. The Beam Good function uses the same range for operating parameters as described above for the Run Fault.

The conditions for Beam good are: Discharge Voltage within ± 12.8 volts, discharge current within ± 1.28 amps, the emission current must be at least 75% of discharge current setpoint, and all gases within 50% of setpoint.

6.2.6 Description of the DB-37 pins

The DB-37 pin analog/digital interface has been described above by sorting out the various remote operating options. Table 6-2 below is provided as a reference with a description of all the pins.

REMOTE/AUTOMATED CONTROL

Table 6-2. Pin descriptions for the female DB-37 connector on the Auto Controller.

Pin Number	Description
1	Emission Current Output. 0-5 volts corresponds with 0 to the maximum emission current in amps for the Emission Power Supply being used. Referenced to pin 7 or 8.
2	No Contact
3	Discharge Voltage Setpoint. 0-5 volts corresponds with 0 to the maximum output voltage for the Discharge Power Supply. Referenced to pin 7 or 8.
4	Emission current set point. 0-5 volts corresponds with 0 to the maximum emission current in amps for the Emission Power Supply being used. Referenced to pin 7 or 8.
5	Auxiliary + 12 volts. Referenced to pin 7 or 8.
6	Emission Voltage Output. 0-5 volts corresponds with 0 to the maximum output voltage for the Emission Power Supply. Referenced to pin 7 or 8.
7	Common.
8	Common.
9	Channel 1 Gas Flow Output. 0-5 volts corresponds with 0 to the maximum output in sccm for the channel 1 MFC. Referenced to pin 27.
10	Channel 3 Gas Flow Output. 0-5 volt corresponds with 0 to the maximum output in sccm for the channel 3 MFC. Referenced to pin 27.
11	Channel 1 Gas Setpoint. 0-5 volts corresponds with 0 to the maximum output for the MFC connected to Channel 1. Referenced to pin 13.
12	Channel 3 Gas Setpoint. 0-5 volts corresponds with 0 to the maximum output for the MFC connected to Channel 3. Referenced to pin 13.
13	Gas Setpoint Common.
14	Gas Channel 3 shut off. Connecting this pin to common pin 7 or 8 will disable the gas flow to the MFC and deactivate the additional MFC relay for channel 3, regardless of the input flow setting.
15	Gas Channel 4 shut off. Connecting this pin to common pin 7 or 8 will disable the gas flow to the MFC and deactivate the additional MFC relay for channel 4, regardless of the input flow setting.
16	Program Select 0. This pin is used in conjunction with the Program Select 1 pin (34) to select a program number of 1 - 4. Uses 0 - 5V logic, pulled high internally through a 5k resistor to +5v. Referenced to common pin 7,8. See Table 6-1 for truth table of pin logic.

17	Remote Setpoint Select. When this pin is connected to common pin 7 or 8, the remote setpoints are enabled and the four programs are not used.
18	DB-37 control select. The pin is connected to common pin 7 or 8 to enable the DB-37 connector. When the connection is left open, the DB-25 is active.
19	Run Fault. When the Auto Controller is enabled, this pin will indicate a run fault if it is at a high logic level of 5 volts. If there is no run fault, then this pin will be at a low logic level of 0 volts. Referenced to pin 7 or 8.
20	Discharge Current Output. 0-5 volts corresponds with 0 to the maximum level of discharge current in amps for the Discharge Power Supply that is being used. Referenced to pin 7 or 8.
21	Discharge Voltage Output. 0-5 volts corresponds with 0 to the maximum level of discharge voltage in volts for the Discharge Power Supply that is being used. Referenced to pin 7 or 8.
22	Discharge Current Setpoint. 0-5 volts corresponds with 0 to the maximum level of discharge current in amps for the Discharge Power Supply that is being used. Referenced to pin 7 or 8.
23	Beam Good 1. Shorted to pin 24 when the operating parameters are in range.
24	Beam Good 2. Shorted to pin 23 when the operating parameters are in range.
25	Keeper voltage output. 0-5 volts corresponds with 0-800 volts. Referenced to common pin 7 or 8.
26	Keeper Current Setpoint. 0-5 volts corresponds with 0 – 2 amps. This should usually be set to 1.5 amps. Referenced to pin 7 or 8.
27	Gas flow Output common.
28	Channel 2 gas flow Output. 0-5 volt corresponds with 0 to the maximum output in sccm for the channel 2 MFC. Referenced to pin 27.
29	Channel 4 gas flow Output. 0-5 volt corresponds with 0 to the maximum output in sccm for the channel 4 MFC. Referenced to pin 27.
30	Channel 2 setpoint. 0-5 volts corresponds with 0 to the maximum output for the MFC connected to Channel 2. Referenced to pin 13.
31	Channel 4 setpoint. 0-5 volts corresponds with 0 to the maximum output for the MFC connected to Channel 4. Referenced to pin 13. output for the MFC connected to Channel 4. Referenced to pin 13.
32	Gas Channel 1 shut off. Connecting this pin to common pin 7 or 8 will disable the gas flow to the MFC and deactivate the additional MFC relay for channel 1, regardless of the input flow setting.

REMOTE/AUTOMATED CONTROL

6-7

33	Gas Channel 2 shut off. Connecting this pin to common pin 7 or 8 will disable the gas flow to the MFC and deactivate the additional MFC relay for channel 2, regardless of the input flow setting.
34	Program Select 1. This pin is used in conjunction with the Program Select 0 pin (16) to select a program number of 1 - 4. Uses 0 - 5V logic, pulled high internally through a 5k resistor to +5v. Referenced to common pin 7,8. See Table 6-1 for truth table of pin logic.
35	No Contact = default. Pin 35 does have special functions for some cases if requested by the customer. See Appendix section Setup for P35 mode.
36	DB-37 Remote Enable. Connect to common pins 7,8 to enable the output. Leave open to disable. Requires pin 18 DB37 Control Select to be tied to common pins 7 or 8 to function.
37	Keeper current output. 0-5 volts corresponds with 0-2 amps. Referenced to common pin 7 or 8.

6.3 Interlock

A two-pin interlock is located on the rear panel. The interlock pins must be shorted to allow operation of the Auto Controller. When the interlock pins are open, the auto controller remains in Standby and the Auto Controller display says Int Loc. The red Open Interlock indicators on the front panels of the power supplies are also on when the Auto Controller interlock is open if there is an RS-485 communication link. The interlock pin descriptions are given below in Table 6-3.

Note that the interlock for the Auto Controller does not open the interlocks for the keeper, emission and discharge power supplies when the Auto controller is in the Gas Only mode or when it is turned off. In these cases, the power supplies function as independent units. These power supplies each have interlocks that prevent operation if the two interlock pins are not closed. The pin descriptions are the same as the interlock for the Auto Controller, but the pins are reversed on the Power Supply. **The four interlocks for the Auto Controller, Keeper Power Supply, Emission Power Supply and Discharge Power Supply must all be used to prevent operation for all contingencies.**

Table 6-3. Interlock connections for the Auto Controller.

Pin Number	Description
1	Interlock Return – Common to chassis
2	Active Low Interlock – Connect to interlock pin 1 to enable.

6.4 Remote Control using the RS-232 Serial Interface

The RS-232 serial interface provides full remote control of the Auto Controller. The Remote/Local select on the front panel must be used to set the unit to remote to enable the remote control.

6.4.1 Interface cable

The interface cable for the Auto controller must be a straight through type and must have a male DB-9 connector to connect to the female connector on the rear panel of the Auto Controller.

6.4.2 Communication settings

The baud rate is 9600 b/s with 8 data bits, one stop bit and no parity. The baud rate can be changed if desired. See the Auto controller setup document in the appendix if another baud rate is required.

6.4.3 Communication overview

The acceptable command/response behavior for the Auto-Controller is described below. The action/reaction of the Auto-Controller to commands may be dependent on several factors or conditions, such as configuration and current system states. These dependencies are outlined below for each command/response category.

6.4.4 Commands, queries and responses

The auto controller can be configured to use two types of cathode/neutralizers. The configuration described in this manual includes only those commands that are used with the Hollow Cathode. Contact KRI for instructions on configuring the auto controller for a cathode/neutralizer other than hollow cathode.

The following conventions are used for the command and query descriptions in the following subsections:

“ “ – Text or numerical values inside double quotation marks indicate the exact response from the Auto Controller. The quotation marks are not included in the actual response.

‘ ‘ – Text inside single quotation marks indicates a state or mode for the auto controller.

REMOTE/AUTOMATED CONTROL

6-9

< > – Text inside arrow head brackets indicates parameters that are included with a command or command string. The brackets are not included when issuing the command.

() – Parentheses surround a numerical value or set point included in the command. The parentheses are not included when issuing the command.

All commands are upper-case sensitive. Lower-case commands and queries will be interpreted as invalid commands.

Any command or query that requires a response must be terminated, at the minimum, with a Carriage Return (CR) character. (ASCII 13 or Hex 0x0D). However, the exact response is determined by whether 'Terse' or 'Verbose' mode is active, as described below in the Verbose Command section. All commands are expected to be terminated with a CR/LF indicated by <cr><lf> in the description below.

6.4.4.1 VRB - Verbose Command

The VRB command sets a flag for more descriptive responses to commands and queries.

The default power-up state of the unit is 'Terse' mode. In this mode, the response to a command is strictly limited to a carriage return (CR) (ASCII 13 or Hex 0x0D). The response to a query will also include values or parameters as a response, but with no descriptive text. Invalid commands or syntactical errors are ignored.

Once the VRB command is issued, the unit will remain in 'Verbose' mode, until it is reset to 'Terse' by a power down/power up sequence. In the 'Verbose' mode, the response to a valid command or query is "OK" followed by CR/LF and the ">" symbol as the next line prompt for the following command/query. The response to a query will also include the requested information with descriptive text. Invalid commands generate an "Invalid Command" response followed by CR/LF and the ">" as the next line prompt.

Command: VRB

Example: VRB<cr><lf>

Response: "OK"

6.4.4.2 COM - Enable RS-232 Command or Status Query

The COM command will enable, disable, or query the status of RS232 remote control of the auto controller depending on the parameter following it.

The default power-up state is 'Disabled'. In order to 'Enable' the RS232 remote control, 'Remote' must be selected using the front panel Local/Remote button. Once 'Enabled', the RS-232 remote control locks out all front panel controls, except for the ON/OFF switch and Gas Select. The Gas Select button is left active to allow monitoring of individual gas flow channels. Once the RS-232 is 'Enabled' the unit must be in 'Standby' in order to return control to the front panel 'Local' or rear analog 'Remote'.

The state of the system can be controlled or queried based on the format of the command. If the ? character is included in the command, the present state of RS-232 remote control will be returned.

Command: COM:<parameter> - 'Enable' or 'Disable' RS-232 remote.

Command: COM? – Get the RS-232 remote control state.

Parameter/Response:

1 = Enabled
0 = Disabled
? = Return current state.

COM:1 – Place unit in 'RS-232 Remote' control.

If the unit is not in front panel remote and standby, the unit issues the following response:

“Unit must be in STANDBY AND front panel REMOTE”.

COM:0 – Disable 'RS232 remote' control.

If the unit is not in 'Standby' when this command is issued, the unit responds with:

“Unit must be in STANDBY”.

COM? – Query of remote control state.

If the unit is in 'Verbose', the response is "Enabled" or "Disabled".

If the unit is in 'Terse', the response is "1", or "0".

Example: COM:0<cr><lf> – Disable RS-232 remote control.

Example: COM:1<cr><lf> – Enable RS232 remote control.

Example: COM? <cr><lf> – Get present output state.

6.4.4.3 *IDN? - Unit Identification Query

The *IDN? command will return a unit identification string. The form of this command follows the SCPI standard query form.

Command: *IDN?

Response:

The KRI Auto-Controller will return information in the following form:
<Manufacturer>,<Model>,<Front panel firmware version>, <Main board firmware version>,<FPGA firmware version>. The form of the firmware version number is month/day/year (MMDDYY).

Example: *IDN?<cr><lf>

Example response: "KRI,AC1,102862,052690,111506"

6.4.4.4 *RST – Reset Command

The RST command will return to the unit to 'Standby' and clear any 'recoverable' error message(s). The unit will also be set to 'Terse' mode

Command: *RST

Example: *RST<cr><lf>

Note: The only 'recoverable' errors are:

HLP 10 – Start Failure
HLP 11– Run Fault
HLP 12– Gas Fault

6.4.4.5 *TST? – Self Test Query

The *TST? command performs a unit self test and report results.

A non-zero return value will correspond to the associated front panel error message as outlined below. If more than one error is active during the query, a string of all active HLP xx numbers will be displayed, where xx are numbers. The response will be the same in 'Terse' or 'Verbose' mode.

Command: *TST?

Example: *TST?<cr><lf>

Error message definitions:

0 = No error. Unit functioning normally.

4 = HLP 4 – Unit not ready.

7 = HLP 7 – Invalid configuration.

9 = HLP 9 – Open Interlock.

10 = HLP 10 – Start fault.

11 = HLP 11 – Run fault.

12 = HLP 12 – Gas fault.

13 = HLP 13 – Internal communication error.

Example Response: "10"

6.4.4.6 OUT - System Level Output Control Command or Status Query

The OUT command 'Enables', 'Disables', or queries the output state of the system depending on the parameter following it.

Command: OUT:<parameter> – To set the output state.

Command: OUT? – To get the output state.

Parameter/Response:

0 = Standby.

1 = Enabled.

? = return current state.

Example: OUT:0<cr><lf> - Put the unit in 'Standby'.

Example: OUT:1<cr><lf> - 'Enable' the unit.

Example: OUT? <cr><lf> – Get present state of output.

If the unit is in 'Verbose', the response will be "Standby" or "Enabled",

If the unit is in 'Terse', the response will be "0", or "1".

If the RS-232 is not enabled, the unit will respond with "Comm Inactive".

6.4.4.7 MDE - Mode Set Command or Mode Query

The MDE command sets or queries the Operating Mode of the system when the unit is in 'standby' and the COM is 'enabled'. The state of the Operating Mode can be queried at any time. In the case of a mode set command it takes a parameter indicated below. If it is a mode query, then it returns the same form as the parameter indicating the current mode.

Command: MDE:<parameter>

Command: MDE?

Parameter/Response:

0 = Auto Gas.

1 = Manual Gas.

2 = Gas Only.

Example: MDE:0<cr><lf> - Put unit in 'Auto Gas'

If COM is active and unit is 'Enabled', the response of the unit is: "Unit must be in STANDBY".

If the COM is not 'Enabled', the command is ignored both in ... 'Terse' and 'Verbose'.

Example: MDE?<cr><lf> - Returns present mode.

If the unit is in 'Verbose', the response is "Auto Gas", "Manual Gas", or "Gas Only".

If the unit is in 'Terse', the response is "0", "1", or "2".

6.4.4.8 BEAM - Beam Good Query

The BEAM query Indicates if a stable operating point has been achieved.

Command: BEAM?

Response is "1" if beam good, "0" if beam not good. This response

is for both 'Terse' and 'Verbose' mode.

Criteria for Beam Good:

Discharge Current within ± 1.28 A.

Discharge Voltage within ± 12.8 V.

Gas Flow at least 50% of setpoint.

Emission current at least 75% of discharge current setpoint.

6.4.4.9 P - Program Value Read/Write Command

The P command selects or queries the active program, or sets or queries the active operating values for a program depending on the parameters included with the command. The operating values are the gas flows for the MFC's, and the currents and voltages for the power supplies. The P command can be used to set or query the values for individual parameters or for a string of parameters depending on the format of the command.

The general form of the program read/write command is:

Command: P<program#>:<parameter> (value)

The <parameter> and (value) fields are optional. The command can be turned into a query by substituting ? for the <program#>, <parameter>, and (value) fields. The interpretation of the query is dependent on where the ? appears as outlined below.

- **Set or query the active program number**

P<program#><cr><lf> - Set active program to <program#>

P<?><cr><lf> - Get active program number.

Acceptable program numbers would be 1 to 4.

Any parameters following the ? character for this command will be ignored.

REMOTE/AUTOMATED CONTROL

6-15

Any parameters following <program#> without the <:> as a delimiting character before the <parameter> field will be ignored.

Example: P4<cr><lf> - Set active program number to 4

Example: P?<cr><lf> - Get active program number

- **Set or query the values for individual program parameters.**

P<program#>:<parameter> (value) – Set specific <program#> <parameter> to (value)

P<program#>:<parameter> (?) – Get specific <program#> <parameter> (value)

There are 9 <parameters> for setting an individual (value). Each of these <parameters>, which are three letters long, are listed below along with the description and the number of significant digits and decimal places shown as x:

1. GS1 – Gas Channel 1, xxx.x
2. GS2 – Gas Channel 2, xxx.x
3. GS3 – Gas Channel 3, xxx.x
4. GS4 – Gas Channel 4, xxx.x
5. DSV – Discharge Voltage Target, xxx.xxx
6. DSI – Discharge Current Target, xx.xxx
7. BEI – Emission/Bias Current Target, xx.xxx
8. BSV – Emission Voltage Target, xxx.xxx
9. KPI – Keeper Current Target, x.xxx

The (values) for each <parameter> may have decimal points and decimal places included or omitted if there are no significant digits beyond the decimal point. However, if the first significant digit falls after a decimal point, then a zero must precede the decimal point or an “Invalid Command” response will be generated. Decimal places beyond the anticipated place will be truncated.

Example: P4:GS1 10<cr><lf> - Set program 4 channel 1 gas flow to 10 sccm.

Example: P1:DSV?<cr><lf> - Get program 1 Discharge voltage value.

Example response in ‘Terse’ or Verbose mode: “200.000”

- **Set or query the values for ALL program parameters**

The parameter <ALL> can be used to set or get all program parameter values. The order of the parameters is the same as the order shown above, as are the significant digits and the decimal point criteria.

P<program#>:ALL (value),(value),(value)...<cr><lf> – Set ALL program parameters to value list.

P<program#>:ALL?<cr><lf> - Get all the program values.

NOTE!! In the following examples, the comma-delimited strings are shown with their mnemonic equivalents listed above. In real use, these abbreviations would be actual numerical values. These numerical values must be valid for the configuration being programmed remotely since the Auto-Controller does not know the maximum ranges of the units attached. The target values returned include the Gas Channels, Discharge voltage and current, Emission/Bias voltage and current, and the Keeper voltage and current.

In using the ALL parameter to set targets, the list of values must be comma delimited and appear in the order shown. Any value that is to remain unchanged can be omitted, but the comma delimiter between parameters must be included in the input string. In the second example, DSI and BSV remain unchanged in the target program.

Example: P1:ALL GS1, GS2, GS3, GS4, DSV, DSI, BEI, BSV, KPI<cr><lf>

Example: P1:ALL GS1, GS2, GS3, GS4, DSV,, BEI,, KPI<cr><lf>

When using the ALL command in 'Terse' mode to get all the program values, they will be returned as a comma delimited string of values in the same order as those shown above. The decimal points and the number of decimal places are shown in the example below.

Example: P1:ALL?<cr><lf>

Example Response:

"10.000, 0.000, 0.000, 10.000, 200.000, 3.000, 3.000, 120.000, 1.500".

REMOTE/AUTOMATED CONTROL

6-17

When using the ALL command in 'Verbose' mode, a list including the name of the value, and the actual numerical value will be returned. A line feed <lf> will separate the returned values.

Example: P1:ALL?<cr><lf>

Example response:

"Gas Channel 1 = 10.000
Gas Channel 2 = 0.000
Gas Channel 3 = 0.000
Gas Channel 4 = 10.000
Discharge Volts = .200.000
Discharge Amps = 3.000
Emission/Bias Amps = 3.000
Bias Volts = 120.000
Keeper Amps = 1.500".

The command can also be used to set or get a single value for a program.

Example: P1:DSV 200 – Set the Discharge voltage for program 1 to 200 volts.

If the auto controller is in the 'Auto Gas' mode, then the setpoint current (DSI) will be the setpoint Discharge current. The gas flow will be the starting flow. Once enabled, the gas flow will be automatically adjusted to maintain the discharge current.

If the auto controller is in the "Manual Gas' mode; either the Discharge current (DSI) or Discharge voltage (DSV) should be set to maximum, while the other is set to the desired operating value. The gas flow determines the discharge parameter that has been set to maximum.

If the Auto Controller is in the 'Gas Only' mode, all the setpoints and queries will still be valid, but only the gas will be enabled when issuing the OUT:1 command. Issuing the OUT:0 command will disable the gas. In using the ALL parameter to set targets, the list of values must be comma delimited and appear in the order shown below. Any value that is to remain unchanged can be omitted, but the comma delimiter between parameters must be included in the input string. In the second example, GS2 remains unchanged in the target program. In 'Gas Only' mode, the supply targets are still

active, so that a series of eight comma delimiters will need to follow the command if the ALL parameter is used.

Example: P1:ALL GS1, GS2, GS3, GS4, , , , , <cr><lf>

Example: P1:ALL GS1, , GS3, GS4, , , , , <cr><lf>

The Auto Controller does not know what (values) are acceptable for the power supply <parameters>. If (values) larger than the output for the power supplies are programmed, the auto controller will set those (values) to the maximum value. However, this is not true for the gas channel values. If a gas channel (value) is larger than the defined maximum, the auto controller will respond with:

“Target value greater than defined max”.

If a gas channel maximum is set to 0 or off, then sending a (value) to that gas channel will generate the following response:

“Gas Channel x disabled” where x is the gas channel number.

It is very important to understand the operating limits of the Ion Source and Hollow Cathode to prevent damage. Review the ion source and hollow cathode manuals to determine appropriate operating conditions. Contact KRI for assistance in establishing operating conditions if necessary.

6.4.4.10 R - Monitor Command for Reading the Actual Feedback Values

The R command is used to get the actual feedback values from the auto controller. It uses similar parameters as those described above for the P command, except that there is no program number required and the ? character is not used.

R:<parameter> – Get the current running (value) of <parameter>

Values are reported in Amps, Volts, or sccm, whichever is appropriate for the selected parameter(s).

Example: R:GS2<cr><lf> – Get current value of Gas Channel 2 feedback.

Example: R:ALL<cr><lf>

Example response in 'Verbose' mode:

"Gas Channel 1 = 18.300
Gas Channel 2 = 0.000
Gas Channel 3 = 0.000
Gas Channel 4 = 10.000
Discharge Volts = 200
Discharge Amps = 3.000
Keeper Volts = 31.400
Keeper Amps = 1.500
Bias Volts = 38.000
Bias Amps = 3.000"

In 'Terse' mode the response will be a comma delimited string of values only in the same as order shown above for the 'Verbose' mode.

6.4.4.11 CFG? – Query current system configuration

The CFG? Command is a query of what the Auto-Controller thinks the current configuration is based on the initial setup.

Command: CFG?

In VERBOSE, the responses are:

"Filament"
"Hollow Cathode with BV"
"Hollow Cathode without BV"
"Gas Only"
"Unknown"

In 'TERSE', the responses are: "0", "1", "2", "3" or "4", respectively.

6.4.4.12 LRN – Learn Command or Learn Query

The current status of LRN can be queried any time. The COM must be active to set the LRN flag. Setting the LRN flag with COM in-active is ignored. Setting the LRN mode using the serial command temporarily overrides the LRN mode setting established in 'setup'. The value in 'setup' is restored on a power down/up or reset.

When LRN is set to on, each program will remember the last running gas flow when the program is disabled and use that gas flow the next time the program is enabled. When LRN is turned off, the program will always start with the originally programmed gas flow.

Command: LRN:<parameter>

Command: LRN?

Parameter/Response: 1 = ON, 0 = OFF

<parameter> can be separated from the command by 1 or less spaces.

Example: LRN:0<cr><lf>

Example: LRN:1<cr><lf>

Example: LRN?<cr><lf>

In VERBOSE, the response is "On", or "Off".

In TERSE, the response is "1", or "0", respectively.

7 DIAGNOSTICS

The following information is intended to facilitate troubleshooting of the Auto Controller and associated power supplies. This information assumes that the Auto Controller and power supplies are connected to power and that all interconnects between power supplies and the ion source cable are made correctly. It is also assumed that all gas connections are in good condition and that the gas circuit is complete from the gas bottle to the ion source.



Warning: Power must be removed from the Auto Controller and power supplies prior to performing maintenance.

7.1 Auto Controller

The auto controller front panel display has an additional function of displaying help codes and error messages. If it becomes necessary to display a help code or an error message, the Auto Controller may switch to standby mode depending on the particular code or message. The front panel display will alternate between displaying “HLP” and a number for the help code. The error messages will be displayed by alternating two abbreviated words. A description of the help codes and the error messages is given below in Table 7-1 along with possible corrective action that may need to be taken.

Table 7-1. Help codes and error messages for the Auto Controller.

Help Code or Error Message	Description	Possible Causes and Corrective Action
HLP 7	Communication for remote RS-485 communication was detected and then lost.	<p>Check the connections of the RS-485 cables.</p> <p>Make sure keeper, emission and discharge power supplies have input power and are turned on.</p> <p>The HLP 7 message will automatically be cleared when communication is restored.</p>

Help Code or Error Message	Description	Possible Causes and Corrective Action
HLP 10	Start failed. The discharge did not start.	<p>Press and release the STANDBY/ENABLE button or remove the remote enable signal to clear the code. The unit remains in STANDBY until STANDBY/ENABLE is pressed again or the remote enable signal is reapplied.</p> <p>Anode has an insulating coating and needs to be cleaned.</p> <p>Hollow Cathode did not start. In this case, HLP 10 is also displayed on the Keeper Power Supply. Review the HLP 10 message for the keeper supply below in Table 7.2.</p> <p>For initial operation at a new operating condition, the gas flow may be too high or too low. Decrease or increase flow.</p> <p>Open or shorted discharge (anode) cable. Inspect in vacuum discharge cable and replace if necessary. Not all damage to the discharge cable may be apparent; in this case replacing the cable may be the only evidence the cable was faulty.</p>

DIAGNOSTICS

Help Code or Error Message	Description	Possible Causes and Corrective Action
HLP 11	Run Failed. The discharge was started and went out.	<p>Press and release the STANDBY/ENABLE button or remove the remote enable signal to clear the code. The unit remains in STANDBY until STANDBY/ENABLE is pressed again or the remote enable signal is reapplied.</p> <p>For initial operation at a new operating condition, the gas flow may be too high or too low. Decrease or increase flow.</p> <p>Open or shorted discharge (anode) cable. Inspect in vacuum discharge cable and replace if necessary. Not all damage to the discharge cable may be apparent; in this case replacing the cable may be the only evidence the cable was faulty.</p>
HLP 12	Initial Gas Failure. The gas flow did not initialize during the start up sequence.	<p>Press and release the STANDBY/ENABLE button or remove the remote enable signal to clear the code. The unit remains in STANDBY until STANDBY/ENABLE is pressed again or the remote enable signal is reapplied.</p> <p>Gas bottle is empty and needs to be replaced.</p> <p>Make sure that any valves in the system are open.</p> <p>MFC is faulty or MFC cable is faulty or disconnected. Repair or replace MFC or cable. Make sure MFC cable is connected.</p>
HLP 13	Master Communication Error.	<p>Switch off the power until the display is dark and then switch the power back on to reset.</p>

Help Code or Error Message	Description	Possible Causes and Corrective Action
Int LOC	Open Interlock. An open interlock prevents the Auto Controller from going to the ENABLE state and holds it in STANDBY	This is a user defined fault in remote operation. Review the interlock scheme for the system in question.
Not Rdy	Not Ready. Auto Controller held in STANDBY.	Insufficient line voltage. Fault will clear itself when the Auto Controller receives sufficient line voltage.

7.2 Keeper Power Supply

The Keeper Power Supply front panel displays have the additional function of displaying help codes and error messages. If it becomes necessary to display a help code or an error message, the Keeper Power Supply may switch to standby mode, depending on the type of code or message. The front panel will display "HLP" and a number for the help code. The error messages will be displayed as one or two abbreviated words. A description of the help codes and the error messages is given below in Table 7-2 along with possible corrective action that may need to be taken.

Table 7-2. Help codes and error messages for the Keeper Power Supply.

Help Code or Error Message	Description	Possible Causes and Corrective Action
HLP 1	Current Latch – A high current was encountered. Power supply latched off to prevent a failure.	Switch off the power until the display is dark and then switch the power back on to reset
HLP 2	Thermal Failure.	Open or shorted thermistor detected. Contact KRI.

DIAGNOSTICS

Help Code or Error Message	Description	Possible Causes and Corrective Action
HLP 7	RS-485 Serial Communication Lost.	<p>Communication for remote RS-485 communication was detected and then lost.</p> <p>Check connection of the RS-485 cables.</p> <p>Make sure Auto Controller has input power and is turned on.</p>
HLP 10	Start failed. The hollow cathode did not start.	<p>Press and release the STANDBY/ENABLE button or remove the remote enable signal to clear the code. The unit remains in STANDBY until STANDBY/ENABLE is pressed again or the remote enable signal is reapplied.</p> <p>Open or shorted cathode or keeper cables. Inspect the in vacuum cable and replace if necessary.</p> <p>No gas flow to the hollow cathode. Due to empty gas bottle, valve off somewhere in the gas supply, faulty MFC, or MFC cable damaged or unplugged.</p>
Hot	Thermal Overload – Internal temperature in the power supply is too hot. Power supply is in STANDBY.	<p>Leave the power supply turned on until the Hot message is cleared.</p> <p>Make sure there is no blockage of the vents on the rear panel.</p> <p>Ambient temperature is too high. Reduce ambient temperature below 40°C.</p>
Not Rdy	Not Ready. – Keeper Power Supply is in STANDBY.	Insufficient line voltage. Message will clear itself when there is sufficient line voltage.

7.3 Emission and Discharge Power Supplies

The Emission and Discharge front panel displays have the additional function of displaying help codes and error messages. If it becomes necessary to display a help code or an error message, these power supplies may switch to standby mode, depending on the type of code or message. The front panel will display "HLP" and a number for the help code. The error messages will be displayed as one or two abbreviated words. A description of the help codes and the error messages is given below in Table 7-3 along with possible corrective action that may need to be taken.

Table 7-3. Help codes and error messages for the Emission and Discharge Power Supplies.

Help Code or Error Message	Description	Possible Causes and Corrective Action
HLP 1	Current Latch – A high current was encountered. Power supply latched off to prevent a failure.	Switch off the power until the display is dark and then switch the power back on to reset
HLP 2	Thermal Failure.	Open or shorted thermistor detected. Contact KRI®.
HLP 7	RS-485 Serial Communication Lost. HLP 7 is displayed.	Communication for remote RS-485 communication was detected and then lost. Check connection of the RS-485 cables. Make sure Auto Controller has input power and is turned on.
Hot	Thermal Overload – Internal temperature in the power supply is too hot. Power supply is in STANDBY.	Leave the power supply turned on until the Hot message is cleared. Make sure there is no blockage of the vents on the rear panel. Ambient temperature is too high. Reduce ambient temperature below 40°C.
Not Rdy	Not Ready. – Discharge Power supply is in STANDBY.	Insufficient line voltage. Fault will clear itself when the power supplies receive sufficient line voltage.

8 APPENDIX

The auto controller is preset to match the product supplied with it so the user should usually not need to enter the setup mode. The setup is provided in case there has been a change to the original product.

8.1 Auto Controller Setup

1. Start with the controller off. Press and hold the Program select and the Acquire Setpoints buttons while tuning on the power switch. Continue holding the two buttons until the LED indicators on the front panel begin to flash. Set the maximum flow for the mass flow controller that will be attached to the four gas channels. Use the Gas Channel Select button to select each channel that will be used, then use the Gas Adjust knob to dial in the correct maximum flow. When finished, press and release the Operating Mode button.
2. At this Point, the display alternately flashes Lrn and on. This is the learn mode for the auto controller. When the auto controller is being used to run the discharge of an end-Hall ion source in auto mode, it will learn how to reach the operating conditions the first time a program is used. The next time, the feedback will home in more quickly. Since this effects the starting gas flow, it may be desirable to turn this off for some applications. Turn the setpoint knob to select off if desired. When finished, press and release the Operating Mode button. Note that the learn mode does not function when operating the auto controller remotely using the remote setpoint option.
3. The display now reads bd3. This is the baud rate selection for RS232 communication with the auto controller. Turn the Gas Adjust knob to select the baud rates. 0=1200, 1=2400, 2=4800, 3=9600, 4=19200, 5=38400, 6=57600, 7=115200. After selecting the desired baud rate, press and release the Operating Mode button.
4. The display should now read L16. This is the led brightness for the indicator LED's (not the display) turn the Gas Adjust knob to obtain the desired brightness from L2 to L64. When finished, press and release the Operating Mode button.
5. The display should alternately flash HC4 and 10. The number 10 is the minimum flow in sccm that the hollow cathode can be adjusted to when using either the Auto Gas or Manual Gas Operating Mode. Use the gas adjust knob to adjust the minimum flow to a value other than 10 if desired. When finished, press and release the Operating Mode button.

6. The display should now be alternately flashing CP4 and 10. This is the cathode purge value. The number 10 is the flow in sccm that flows even when the Auto Controller is in standby if either the Auto Gas or Manual Gas Operating Mode are selected. Use the Gas Adjust knob to dial in the desired purge gas flow, or dial in 0 if no purge gas is desired. When finished, press and release the Operating Mode button.
7. The display should now read b, followed by a number. This controls how many times the Auto Controller beeps if the operating parameters have been changed without saving them, or when a fault occurs. Turn the Gas Adjust knob to select the desired number of beeps. When finished, press and release the Operating Mode button.
8. The display should now be alternating between P35 and a number. This determines the functionality of pin 35 on the DB37 connector. Selectable values are 0,1,or 2 which are described below.
 - 0 = pin 35 allows gas only mode selection. Tying pin 35 low to pin 7,8 will change the operating mode to gas only. Requires the following.
 - Unit must be in remote (press Local/Remote button on front panel so Remote LED is lit).
 - DB37 Select (pin 18) must be tied low to pin 7,8 (common).
 - Remote Setpoint Select (pin 17) must be tied low to pin 7,8 (common).
 - 1 = pin 35 functions as the gas ratio pin. Tying this pin low to pin 7,8 while the output is on will cause the unit to save the total gas flow being used then look at the rear analog gas setpoints and use them to adjust the gas flow to these new ratios. For example the user may start with 100% argon and 0% oxygen then switch to 80% argon 20% oxygen after running. Requires the following:
 - Output must be enabled (source on).
 - Unit must be in remote.
 - DB37 Select (pin 18) must be tied low to pin 7,8 (common).
 - Remote Setpoint Select (pin 17) must be tied low to pin 7,8 (common).
 - Pin 35 must be tied low for > 1 second to activate.

- 2 = pin 35 allows the user to put the unit into remote mode via the DB37 connector. Tying pin 35 low to pins 7,8 (common) will put the unit into remote control.
 - This will lock the user out from the front panel.
 - Removing the connection to pin 7,8 will give the user access to press the front panel Local/Remote button to put the unit back into local control.
- 9. The display should now alternately flash Etr and a number. This is the run timer setting in seconds. This is used to have the source run for a controlled amount of time after it is enabled. The timer starts when the source is enabled and shuts off the source when the timer expires. Setting this to 0 will disable this feature.
- 10. The display should now be alternately flashing d25 and the number 1 or 2. This controls the DB25 analog I/O for the Mark I or Mark II power supplies. Turn the Gas Adjust knob to either 1 for Mark I or 2 for Mark II I/O. When finished, press and release the Operating Mode button.
- 11. The display should now alternately flash PrE and a number. This is the gas preflow timer in seconds. This sets how long the gas flows prior to actually enabling the source after an output enable is received. This can be set from 3 to 25.5 seconds. Turn the Gas Adjust knob to set this to the desired value. When finished, press the Operating Mode button to exit the setup menu.

The Auto Controller has now been configured and is ready to use.

This Page Is Intentionally Blank

9 WARRANTY

Seller warrants to the Buyer that new Products will be free of defects in material and workmanship and shall conform to applicable specifications for a period of one (1) year from date of shipment. Seller does not warrant uninterrupted or error-free operation of the firmware. Seller's obligation under these warranties is limited to repairing or replacing, at Seller's option, defective Products. These services will be performed, at Seller's option, at either Seller's facility or Buyer's business location. For repairs performed at Seller's facility, Buyer must contact Seller in advance for authorization to return Products and must follow Seller's shipping instructions. Freight charges and shipments to Seller are Buyer's responsibility. Seller will return the Products to Buyer at Seller's expense. All parts used in making warranty repairs will be new or of equal functional quality. Seller assumes no liability under the above warranties and the following are specifically excluded from all warranties including Product defects resulting from (1) abuse, misuse, or mishandling; (2) damage due to forces external to the Product including, but not limited to, Force Majeure, power surges, power failures, defective electrical work, foreign equipment/ attachments, or utilities, gas or services; (3) the use of parts not supplied by the Seller; (4) replacement and repaired parts, and consumable items (including, but not limited to, filaments, insulators, grids, reflectors, isolators, vacuum cables, and connectors); (5) improper operation or maintenance, servicing, installation or (6) failure to perform preventive maintenance in accordance with Seller's recommendations (including keeping an accurate log of preventive maintenance). In addition, this warranty does not apply if any Products have been modified without the written permission of Seller or if any Seller serial number has been removed or defaced. THIS WARRANTY IS GIVEN IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY, TITLE, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE OR USE, OR OTHERWISE. IN NO EVENT SHALL SELLER'S TOTAL LIABILITY TO BUYER EXCEED THE PURCHASE PRICE OF THE PRODUCTS.

For service or repair, contact KRI® at:

Kaufman & Robinson, Inc,
1330 Blue Spruce Drive
Fort Collins, CO 80524
Tel: (970) 495-0183
Fax: (970) 484-9350

Please include the following information relating to the defect and the item to be returned:

Product
Serial number