



RF VII, Inc.

RF-6-XIII RF GENERATOR USER MANUAL

Document # 9055-6001-D

COPYRIGHT 2018 RF VII, Inc.
104 Church Street, Newfield, NJ
08344
All rights reserved 2018

WARNING

To avoid possible shock or fire hazards, connection of this product should be performed in compliance with the ANSI electrical code. Operation, Installation, and Maintenance should be performed by a qualified Technician or Engineer.

WARRANTY STATEMENT

All our products are warranted to the original purchaser against defective materials or workmanship for a period of one year from date of delivery. RF VII Inc. will at its own option repair or replace all defective material returned (freight prepaid) during the warranty period. Provided the unit is properly repackaged and returned without damage done by abuse or mishandling. (See Section 5 for shipping information)

PROPRIETARY NOTICE

These documents are considered Proprietary and confidential. All reproductions must be approved by RF VII, Inc.

RF-6-XIII Instruction Manual

<u>SECTION</u>	<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
1	<i>Technical Specifications</i>	I
2	<i>Description</i> General Mechanical	II
3	<i>Controls and Indicators</i> Remote Panel functions Rear Panel Functions Front Panel Controls	III-VI
4	<i>Installation</i> Remote connections RS-232 connections	VII-XI
5	<i>Schematics</i> Service Glossary	XII-XIV

SECTION 1

RF-6-XIII Instruction Manual

Section 1

Technical Specifications

RF GENERATOR

Electrical

Power Requirements	110-240Vac 50/60Hz
Power Consumption	1700 Watts
Power Connector	IEC-320C-14 EMI Filtered

Output

Frequency	13.56 MHz
Power Rating	600 Watts
Impedance Rating	50 Ohms
Reflectant Limit	60 Watts


Mechanical

Height	7.00 " / 17.8 cm
Width	8.00 " / 20.3 cm
Depth	19.00 " / 48.3 cm

Miscellaneous

Cooling	Air / 190 CFM
Interface Connector	15 pin D type (female) EMI/RFI Filtered
RF Output Connector	N type
Pulse Input	BNC (Optional)
CEX Input/Output	BNC type
Weight	22 lbs
RS-232	9 Pin D (Optional)

<u>Safety Features</u>	5 Vdc system close loop to ground
Interlock Loop	Internal heat shutdown Interlock <42 C
Over Temp	AC overload protection
AC Breaker	AC fused second input line
AC Fuse	EMI/RFI Filtered
Input Remote control DB 15	



SECTION 2

RF-6-XIII Instruction Manual

Section 2

Description

General

The RF-6-XXII RF Generator is designed for power delivery of 13.56 MHz at 600 Watts of output. It requires the use of RF transmission cable (50 ohm / RG-393) to couple power into an Auto tuner (ATN-10 or 15) or 50-ohm resistor load. Power is read on the front panel or remote connector provided on the rear of the generator. There are three types of operational controls, front panel, remote, and optional RS-232. These functions are more explained in the operation section of this manual.

Mechanical

The unit is a 19" rack mount chassis with a black front panel. It is also enclosed in yellow iridite aluminum for RF conductive ground purposes. The DC power supply chassis is L molded for ease of assembly and repair purposes. All metal is 0.090" or thicker for extra support during handling and shipping.

SECTION 3

RF-6-XIII Instruction Manual

Section 3

Controls and Indicators (For units with Front panel option)

Indicators

There are several indicators located on the front panel of the RF generator. The two red led indicators are for ***RF forward and reflectant*** power readings. The four indicators (LED's) are operational mode detection parameters.

- Intlk** = Illuminates when external interlocks are **not** satisfied.
Temp = Illuminates when heat sink temperature exceeds safe levels.
Remote = Illuminates when remote operation is activated on back Panel or when the optional RS-232 mode is enabled.
Cex = Illuminates when the CEX pin is pulled down low (J1). This allows for an external source input to be applied to J2 BNC input for dual plasma operation using 2 RF sources.

RF Enable Off = Illuminates when RF generator is idle and RF is not enabled.

RF Enable On = Illuminates when RF switch is activated upon depressing (Enabled) red RF on button.

DC Bias Control = By pulling Pin 13 to ground this activates DC Bias control. DC Bias voltage from the Auto-Tuner Is fed to Pin 12, and the set-point control will now Control the Bias Voltage created in the chamber. This gives better control over the systems plasma Developed at the source, rather than back at the RF Generator.

Controls

There are three types of operational controls, ***Remote operation, RS-232,*** and ***Front Panel operation.***

1. Using Front Panel operation a preset set-point can be achieved by pressing and holding the blue switch and rotating the power set knob. Depressing the red switch will toggle RF ON and RF OFF.
2. The remote 15 pin D connector allows the customer's system the option of parameter control of the RF Generator. See connector pin out in the installation portion of this manual.
3. RS-232 is a 9 pin D connector for serial communication to systems Computer, Gui, PLC, or Microprocessor controls.

RF-6-XIII Instruction Manual

SECTION 3


Remote Interface Operation

- 1- **External Interlock** is a safety circuit which uses an internal pull-up resistor. This will disable the RF power on the generator if the analog interface connector or dummy plug is not connected. The RF will not enable if the interlock is not satisfied.
- 2- **RF On** is an input function with an internal pull-up resistor which can only be activated when all protective circuits are satisfied. If the generator is turned off or a protective circuit shuts off the RF at any time, all protective circuits must be re-satisfied and the control line must transition from high to low for the RF to be reactivated.
- 3- **Set-point Input** is a differential input which works together with the set-point return. The set-point input must be a positive voltage from 0 to 5 volts greater than the set-point return. The maximum voltage that can be used is 5.5 volts.
- 4- **Set-point Return** is also a differential input and works together with the set-point input. The set-point return must be from 0 to 5 volts less than the set-point input. When the set-point input and set-point return have the same voltage, the power level is at 0 watts.
- 5- **RF ON & OK** is an output function with an internal pull-up resistor. It tells the RF status of the generator. If the voltage level is low then the unit is operating correctly with RF on and low reflectant. If the voltage is high, then the unit is not running properly and RF can either be on with high reflectant or the RF is off.
- 6- **CEX Enable** is an optional circuit that allows the generator to be used with multiple generators using the same crystal signal. When low voltage is put to the pin, CEX is enabled and the generator is ready to be used as a slave unit.
- 7- **Reflectant Monitor** is an output function. It gives a voltage from 0 to 5 volts which shows how much reflected RF power the unit is receiving. Sealing is 5 volts which equals the rated power.
- 8- **Forward Monitor** is an output function. The line gives a voltage from 0 to 5 volts which shows how much forward RF power the generator is outputting. An output of 5 volts means rated forward power.
- 9- **Ground** is from pin 9 to 13. For proper operation of the generator, the system controlling the generator must be connected to at least one of these pins to ensure a common ground between the system and the generator.
- 14- **RF Enabled** tells the status of the RF as either on or off. When RF is off there is a short to ground (closed connection), and when RF is on the connection is open to ground (open connection). This output is used in conjunction with the matching network preset operation.
- 15- **Local/Remote Select** is an input function. It allows the user to switch between local control (optional front panel) and remote control which is also called analog interface. This line has an internal pull-up resistor. An input of 5 volts is local control, and 0 volts is remote control.

RF-6-XIII Instruction Manual

Section 3

Rear Panel




Connections

Ac Power	Single phase Hubble Male 20 A single phase
J1	Remote interface to system hardware. 15 Pin D (Female)
J2	RF output N Connector
J3	Optional RS-232 (Female 9 Pin)
J4	CEX Input
J5	CEX Output

RF-6-XIII Instruction Manual

Section 3

RF Generator Front Panel Features



Front Panel Layout	
A	<u>RF Output Display</u> -displays RF power output in watts
B	<u>RF Reflected Display</u> - displays reflected RF power in watts
C	<u>RF Enable Switch</u> - turns RF on and off (toggle)
D	<u>RF Power Set Knob</u> - adjusts the RF power output
E	<u>RF Power Pre-set</u> -Hold in and turn the RF power set knob to pre-set RF output in watts
F	<u>INTLK</u> - LED is on when external interlock is not satisfied
G	<u>TEMP</u> – LED is on when heat sink temperatures exceed safe levels
H	<u>REMOTE</u> -LED is on when remote operation is activated. Also indicates when RS-232 option is in use.
I	<u>CEX</u> - LED is on when the CEX is enabled allowing for slave mode operation
J	<u>RF OFF</u> - LED is on when generator is idle
K	<u>RF ON</u> - LED is on when RF is active. Caution! Do NOT touch RF connector when this LED is on!
L	Circuit Breaker acts as power on/off switch

SECTION 4

RF-6-XIII Instruction Manual

Section 4

Installation

Unpacking

Inspect RF Generator package for any shipping damage before opening container. Now remove the RF Generator from container and remove antistatic wrap from unit. Check for any damage and condition of product should be new.

Mechanic Connections

Install RF Generator into desired enclosure (19" Rack) with some bottom support. For proper operation, install RF Generator ensuring good grounding to the system.

Electrical Connections

Connect AC input and remote connections as directed in this manual. Connect RF Cable N connector to generator and then to a dummy load or Matching Network. This RF Cable should be in lengths of 12' feet (Standard) or 4' increments for shorter requirements. Improper lengths could void warranty of RF generator. Install 15 pin dummy connector with interlock pulled low for stand alone front panel operation. Or use section 4 and hook-up remote analog function control lines if front panel is not available.

Set-up & Operation

After all connections satisfied, (15 pin remote, AC Plug, and RF Cable) turn on Breaker and/or AC power on switch. Unit's fans should turn on with front panel or remote giving idol state status signals.

FRONT PANEL: Check front panel indicators for status and operation readiness. If the interlock (Pin 1 low) is satisfied (interlock indicator LED should be off) you should be able to turn RF ON with the Front panel button (RF enable). After getting the RF On Indicator illuminated, dial the power knob up (Dummy Load) to maximum rated watts, to ensure unit is fully functional. Or, if using an auto-tuner dial up power up until tuner eliminates reflectant power, while reaching your desired Incident power.

REMOTE PANEL: If the interlock (Pin 1 low) is satisfied, then toggle Pin 2 to ground on the remote connector to enable RF ON. Check status line on Pin 5 (should be low) indicating RF power is on. Now by applying a differential DC set-point (0-5Vdc) across Pin 3 (Set-point return is Pin 4) you should see power readings on pin 8 close to the input set-point voltage. Test unit to maximum rated power, which should be 5 Vdc set-point input with a close 5 Vdc monitor output.

If you have any problems contact a service engineer at RF VII, Inc.

Warranty

All units have a one year depot warranty effective from the date stamped on the serial tag.

RF-6-XIII Instruction Manual

Section 4

Installation

Remote Control Connections (15 pin D Female)

J1

(1)	External Interlock (Low to Satisfy Interlock)
(2)	RF ON Enable (Low to activate)
(3)	Set-Point input (0-5Vdc)
(4)	Set-Point return
(5)	<i>RF ON & ok</i> (indicator/output) (Low = ok)
(6)	CEX Enable (Low to activate)
(7)	Reflectant monitor (5vdc = 600 watts)
(8)	Incident/Forward monitor (5vdc = 600 watts)
(9)	Ground
(10)	Ground
(11)	Ground
(12)	DC Probe Input
(13)	DC Probe control (pull low for activation)
(14)	RF Enabled for PT-II-CE Presets (low = RF off)
(15)	Local / Remote Select (low / Remote)

RF-6-XIII Instruction Manual

Remote Interface Operation

SECTION 4

Remote Connector Pin out

Pin	Description	In/Out*	Activate
1	External Interlock (IPR)**	In	High = Not Satisfied Low = Satisfied
2	RF ON (IPR)**	In	High = RF Off Low = RF On
3	Set-point Input	In	Differential Input of Zero to 5 Volts 5V = Rated Power
4	Set-point Return	In	
5	RF ON & OK (IPR)**	Out	High = Not Ok Low = Ok
6	CEX Enable or ATN Arc Supression (Optional)	In	High = CEX Disable Low = CEX Enable
7	Reflectant Monitor	Out	Zero to 5 Volts 5V = Rated Power
8	Forward Monitor	Out	Zero to 5 Volts 5V = Rated Power
9	Ground	None	None
10	Ground	None	None
11	Ground	None	None
12	Bias Voltage Input	In	Zero- 1 Volt Appox.
13	Bias Voltage Input	In	Ground / Optional VTL
14	RF Enabled (Status) (Used for PT-II-CE Presets	Out	Open = RF On Closed = RF Off
15	Local/Remote Select (IPR)**	In	High = Local Low = Remote

*In/Out is used to describe the functionality of the pin as either an input or an output.

**IPR (Internal Pull-up Resistor) must have a transition in voltage to activate.

RF-6-XIII Instruction Manual

SECTION 4

RS-232 Operation

RS-232 is an optional way to control the generator through serial communications to a systems computer or microprocessor.

RS-232 Setup

Baud Rate: **9600**

Parity: None

Data Bits: 8

Stop Bits: 1

RS-232 Pin out DB9 Female Connector

Pin	Initials	Description
1	DCD	Data Carrier Detect
2	TxD	Transmit Data*
3	RxD	Receive Data*
4	DTR	Data Terminal Ready
5	SG	Signal Ground
6	DSR	Data Set Ready
7	RTS	Request To Send
8	CTS	Clear To Send
9	RI	Ring Indicator

*For use with a straight serial cable.

RS-232 Commands

Command	Description
HI[CR][LF]	Enter RS-232 Mode
BYE[CR][LF]	Exit RS-232 Mode
P #####[CR][LF]	Set Power
RFON[CR][LF]	Turns RF On
RFOFF[CR][LF]	Turns RF Off
G+[CR][Lf]	Pulse Mode On
G-[CR][LF]	Pulse Mode Off
F ##[CR][LF]	Pulse Frequency 1Hz to 999Hz, 1Hz resolution
D ##[CR][LF]	Duty Cycle 10% to 90%, 5% resolution
?[CR][LF]	Status Report

Note: Commands are **NOT** case sensitive.

RF-6-XIII Instruction Manual

SECTION 4

RS-232 Operation

Status Report Example

The response from the generator is as follows:

?X SET FWD REF[LF][CR]

SET is the set point power in watts, 1-4 digits

FWD is the forward power in watts, 1-4 digits


REF is the reflected power in watts, 1-4 digits

X is an ASCII character, 0 though 7

X is actually a three bit binary number padded out to eight bits so that it will display as a numeric character. The number's bit configuration indicates the following:

Bit	True	False
DB0	RF OK	RF NOT OK
DB1	External Interlock OK	External Interlock NOT OK
DB2	RF ON	RF OFF

* Gui Software available for RS-232 communication



SECTION 5

RF-6-XIII Instruction Manual

Section 5

Schematics / Service

We have not included schematics, but they are available by request of your qualified service personnel. These drawing are proprietary and should not be reproduced for any company other than the original OEM customer.

For any parts or service please contact RF VII Inc. by the following listed methods. When returning equipment, please insure that you properly package the units. If you are unsure please contact RF VII Inc. for proper procedure. You can also request product packaging to be shipped to your location for a nominal fee.

RF VII Inc.
104 Church Street
Newfield, NJ 08344


Ph: 856-875-2121

Fx: 856-875-2119

Url: www.rfvii.com

Em: rfvii@yahoo.com

RF-1-3-6 Chassis Block Diagram



SYMBOL GLOSSARY



Symbol means a product has met the European Unions Consumer Health and Environmental Safety Requirements.



Symbol for the Certified Body for the International Electro-Technical Commission. Which is the worldwide System For conformity testing and certification of Electro-technical Equipment and Components (IECEE)



Electrical Shock Hazard Symbol



General Warning Symbol



Non-Ionizing Radiation Symbol

Glossary

AC – Alternating Current

ANSI electrical code – (American National Standard Institute)

CEX - An abbreviation for Common Exciter.

DC – Direct Current

GUI – **G**raphical **U**ser **I**nterface – Type of user interface that allows humans to interact with electronic devices such as computers.

HARMONICS – A component Frequency of the Signal that is an integer multiple of the fundamental frequency.

HERTZ- is equal to a CYCLE, which is the method of frequency/time of a given signal. Depending on your age is which term you use.

KHz – Kilo Hertz, 1000 Hertz / Cycles per second

IMPEDENCE – is the measurement of capacitance or inductance in a reactive circuit.

Unit of measurement is in ohms of reactance (Not to be confused with electrical resistance) and classified Inductive or Capacitive.

MHz – Mega-Hertz, 1,000,000 Hertz / Cycles per second

RESONANCE- is when capacitance and inductance, in a reactive circuit, cancel each other.

Roman Numeral Frequency Conversion Table;

I = 1.2 MHz

II = 2.0 MHz

RF- VII = RF- Seven “Company Pronunciation”

XIII = 13.56 MHz

XXVII = 27.12 MHz

XL = 40.68 MHz